


Instructions for HP Color LaserJet Pro M255/M282/283 series



Often time, the OEM will release a new firmware update to block out the aftermarket chip solution. This is to prevent the user from enjoying the continuous saving of the aftermarket toner solution. To avoid such trouble in the future, it is highly recommended to disable the printer's automatic firmware update feature on your printer.




1 Locate the "Set up" option on the printer panel and click on it.




2 Click on the "Service" option.



3 Click on the "Laser Jet Update" option.




4 Click on the "Next" option.



5 Click on the "Manage Updates" option.



6 Click on the "Allow Updates" option.



7 Click on the "NO" option and the printer is ready for use.